







## Codey Rocky Quick Start Guide



# Contents


List of items.....	1
Assemble Codey Rocky.....	2
Power on.....	2
Software download .....	3
Makeblock app .....	3
mBlock 5.....	3
Connect your Codey Rocky .....	4
Mobile device (mobile phone & tablet) .....	4
PC.....	4
Code Codey Rocky.....	4
Charge .....	5
Safety Instructions .....	5
Specifications.....	6

# List of items

 <p>Codey</p>	 <p>Rockey</p>	 <p>Lanyard</p>	 <p>Color card</p>
 <p>Name sticker</p>	 <p>Micro USB cable</p>	 <p>USB cable</p>	 <p>Wheel hub</p>

# Assemble Codey Rocky

Rocky needs to work with Codey.



## Power on

Press the power button to start the product and the power indicator light will be solid on.



# Software download

Codey Rocky is a programmable robot that is playable and educational. It supports mBlock 5 and the Makeblock app.

## Makeblock app

Quick start by using the Makeblock app.


Search "Makeblock" in App Store or Google Play to download the Makeblock app.



## mBlock 5

Achieve more ideas by using mBlock.

Download the software for PC: <http://www.mblock.cc/>.




# Connect your Codey Rocky

Codey rocky can be connected to your PC, mobile phone, and tablet.

## Mobile device (mobile phone & tablet)

Open the app and enable the Bluetooth of your device. Put your mobile phone or tablet close to Codey and it will be connected through Bluetooth automatically.



## PC

Use the Micro USB cable to connect Codey to your computer and open mBlock 5 to use it.



# Code Codey Rocky

1. Programming  
Drag the programming blocks to start your programming journey.
2. Upload  
Upload programs to Codey.
3. Have fun

Run the program to have fun with your Codey Rocky.


#### 4. Share

Share what you've done with friends.

For details about how to code Codey Rocky, go to [support.makeblock.com](https://support.makeblock.com) and search for Codey Rocky.

## Charge

Connect Codey to your computer or power adapter via the Micro USB cable to charge for Codey.



## Safety Instructions

- Recommended for children of ages 6+.
- Not suitable for children under ages 3.
- Children need to be accompanied by adults when using the product.
- To avoid damage as a result of falling down, please don't put the product on the edges of high places.
- To avoid product damage, please don't disassemble, repair or modify this product yourself.
- To avoid product damage or safety incidents, please don't place this product in water, fire, environments of humidity or high temperature.
- Please don't use or charge this product in any environment with a temperature outside the operating temperature range of this product.
- Please fully charge the product for storage and recharge it every 3 months when the product is left unused.
- Please use the recommended adapter (5V / 1A adapter) to charge the product.
- The adapter used to charge the product (not included in the package) cannot be used as a toy.

- Please ensure that the product is powered off and disconnected from any external power supply when liquid is used to clean the product.
- The product should be connected to the power supply in strict accordance with the limit on the number of power supplies.
- Please check the wires, plugs, housings, or other parts periodically and stop using them if any damage has been found until they are well repaired.

## Specifications

Battery	950 mAh lithium battery
Pogo Pin magnetic interface for current output	DC 5 V
Pogo Pin magnetic interface for voltage output	< 2 A
Micro USB input voltage	DC 5 V
Micro USB input current	1 A
Transmission mode	Wi-Fi / Bluetooth / USB
Bluetooth distance	Within 10 meters (empty areas)
Wi-Fi distance	Within 10 meters (empty areas)
Operating temperature	0°C–40°C
Storage temperature	-10°C–55°C